

Firmware upgrade instructions for the Conceptronic C54PSERVUM print server firmware version 2.331

These instructions explain how to upgrade the firmware of the Conceptronic C54PSERVUM print server.

1. Start the “MFP Server Control Panel” from your desktop or the start menu.
2. The available print servers are displayed. Select the print server you want to upgrade.

Default print server name : “C54PSERVUM - xxx.xxx.xxx.xxx”

***Note:** If the print server you want to upgrade is not displayed, you might need to click on the “Refresh Server List” button.*

3. Click “Configure Server”. You will be asked to enter the administrator and password. Enter these and click on the “Login” button.

Default administrator : “admin”

Default password : “admin”

4. The server configuration window will be displayed, click on the “Maintenance” tab.
5. Click on the “Open” button and select the firmware file.

Default firmware file name : “C54PSERVUM_FW_UPD_v2.331.bin”

6. When you have selected the firmware file, click on the “Upload” button. The firmware will be upgraded.
 7. Once the progress bar reaches 100%, the server will be restarted. You will get the message “The Server is restarting”. Wait it for to finish and click the “Close” button.
 8. The firmware of your C54PSERVUM has been upgraded and it is ready to be used again.
-

Release notes for the Conceptronic C54PSERVUM print server
firmware version 2.331

V2.331 05/13/2008

Fixed:

- Wrong header in the e-mail option.
-

V2.33

- Initial release.
-