

Conceptronic CMED3PLUS Firmware Upgrade Instructions



"This firmware is only suitable for the CMED3PLUS device with the firmware versions **OMP07T101806A.rom** and **OMP07T101906A.rom**"

If the firmware version is lower than OMP07T101806A or OMP07T101906A, then you need to update the firmware with OMP07T101806A first.

Extract the file to the default location.

Firmware file:

C:\conceptronic\CMED3PLUS\FW\OMP07T101806A.rom

C:\conceptronic\CMED3PLUS\FW\OMP07T101906A.rom

The Conceptronic CMED3PLUS is equipped with a firmware upgradeable chip. This function makes it possible to improve the device and add new features.

To upgrade the firmware of the CMED3PLUS, follow the steps below:

1. Connect the CMED3PLUS to your computer.
2. Copy the folder **FW** with the extracted files "**OMP07T101806A.rom**" and "**OMP07T101906A.rom**" to CMED3PLUS.
3. Safe-remove the CMED3PLUS from the computer.
4. Connect the CMED3PLUS to your TV or Monitor.
5. Power-on the CMED3PLUS with the remote.
6. Select the folder **FW** in the root of the hard disk.
7. ! Remove the FW folder from the hddisk by way of the computer after the update.

NOTE: The device will begin to upgrade the firmware. This can be noticed in the upper left corner (Erasing, Writing).
When it is finished, it will notify you shortly and the screen will turn black.
THE DEVICE IS STILL ON!!
Press the 'POWER' button on the remote control to turn OFF the device.
Press the 'POWER' power button to power ON the device.

Your CMED3PLUS is now upgraded and ready to use!

NOTE: IF YOU DON'T FOLLOW THE ABOVE STEPS, YOU CAN CAUSE SERIOUS DAMAGE TO THE CMED3PLAY, AND IT WILL VOID YOUR WARRANTY!!

"EXTRA INFORMATION" !

FIXES OMP07T032707A:

DVD Navigation fix:

1. Fast Forward and Fast Back
2. Several DVD playback issues solved

FIXES OMP07T101806A:

1. Issue of time display during playing: done.
2. Issue of PAL default setting: done.

FIXES OMP07T092106A:

1. Autostart feature added (bug fixed)
2. Some other minor changes internally.
3. DVD navigation support

For DVD playback:

Copy all files of the DVD disc to a folder to the harddisk of the CMED3PLUS

You can name the folder ie. DVD_DISC1;

In this folder the DVD Structure must be remain: VIDEO_TS

The AUDIO_TS is not necessary but of course customers can or may copy that one also

1. To start-up the DVD navigation option: position the cursor to the DVD_DISC1 folder and press the RIGHT cursor button to start playing the DVD, if pressing Enter you will see the content of that folder. Go back to folder index and press right button to start the DVD playback
2. Subtitle options: press "SUBTI" to select a proper subtitle.
3. Audio Language options: press "AUDIO" to select proper language.
4. File info: Press "FUNC" to display the file info of playing file.
The FUNC function is enabled by default. So always press FUNC to remove timer.
5. Play forward/backward: Press FF/FR to play fast forward and backward.
6. Chapter select: Press PREV/NEXT to change movie chapter.
7. Pause and Play: Press PAUSE to pause file playing.
8. Stop navigation: Press STOP to exit navigation mode.
9. Zoom: Press ZOOM to zoom in/out display.
10. Volume control: Press MUTE/VOL+/VOL- to turn volume up/down or mute on/off.
11. Repeat playing: Press A-B to repeat playing.
12. Repeat mode options: chapter repeat, title repeat, and off repeat.