

Conceptronic CMEDHOST Firmware Upgrade Instructions
for firmware version: 1.57 / MP05HT081408A

A. Upgrade information

The Conceptronic CMEDHOST is equipped with an upgradeable firmware chip. This function makes it possible to improve the device and to add new features.

Note: This firmware upgrade for the CMEDHOST can only be applied to devices with firmware version 1.55B (MP05HT052908A) or higher. If you have a lower version you need to upgrade to version 1.55B before you can apply this firmware upgrade.

B. Upgrade procedure

1. Copying the firmware files to a USB stick or a memory card

- 1.1 If you have downloaded the firmware upgrade from www.conceptronic.net, you have a ZIP file containing a folder named 'Firmware' and three documentation files.
- 1.2 Connect the USB stick or memory card to your computer.
- 1.3 Copy the 'Firmware' folder including all its content to the USB stick or memory card.
- 1.4 Remove the USB stick or memory card from your computer with the 'Safely remove hardware' option.
- 1.5 Disconnect the USB stick or memory card from your computer.

2. Updating the firmware

- 2.1 Make sure the CMEDHOST is connected to a TV or monitor.
- 2.2 Turn on the CMEDHOST with the remote control.
- 2.3 Connect the USB stick to the CMEDHOST or slide the memory card in the right card slot of the CMEDHOST.
- 2.4 Select the 'Firmware' folder by using the navigation buttons on the remote control.
A confirmation screen will be displayed asking if you want to replace the current firmware with a new one. Choose 'Yes'. The upgrade process will start. This is visible in the upper left corner with the terms 'ERASE' and 'WRITE'.

Note: *The CMEDHOST must not be turned off during the upgrade process. Doing so will result in an unusable product.*

- 2.5 As soon as the upgrade process is completed, the screen will go black.

Note: *The device is still turned on. You need to manually turn off the device by pressing the 'POWER' button on the remote control. You can completely turn the device off by turning off the switch on the back side of the device.*

- 2.6 Remove the USB stick or memory card from the device.

Note: *Never do this when the device is turned on and the upgrade process is busy. This will result in an unusable product.*

3. Checking the firmware version

- 3.1 Make sure the CMEDHOST is connected to a TV or monitor.
- 3.2 Select a folder by using the navigation buttons on the remote control.
- 3.3 Press the '**FUNC**' button on the remote control, select '**PROPERTIES**' and press the '**Enter**' button.
- 3.4 Now press the '**Pause**' button (**II**) five (5) times in a row.
- 3.5 Leave the current screen by pressing the '**FUNC**' button.
- 3.6 When the '**Fast Forward**' button (**>>**) is pressed, the current firmware version will be shown.
This must be: **VER 32-O MP05HT071108A-2L**.
- 3.7 If the version isn't shown long enough, you need to press the '**Fast Forward**' button again.
- 3.8 If the displayed version isn't the same as the version described at point 3.6, then you need to repeat the upgrade procedure as described in chapter B.

B. Release notes

1.57 / MP05HT081408A **August 14, 2007**

Added:

- Cyrillic Subtitle support.
-

1.56 / MP05HT071108A **July 11, 2008**

Fixed:

- Pictures displayed using the VGA output have black borders around them.
-

1.55B / MP05HT052908A **May 29, 2008**

Added:

- Option to turn off the video preview.
Go to “Setup” » “General settings” » “Preview” to turn it on or off.
-

MP05HT060107B **June 1, 2007**

Fixed:

- “Locked Device” error on some models.
-

MP05HT070706A **July 7, 2006**

Fixed:

- Equalizer setting is not saved into memory.
 - Parts of the German language are not correct.
 - Cursor does not return to the file which was selected before playback.
-

MP05HT060806A **June 8, 2006**

- Initial release.
-