

Conceptronic CSM3PL Firmware Upgrade Instructions for Cyrillic firmware version OMP07ST011208A / 1.60



A. Suitable firmware versions

Note: This firmware upgrade for the CSM3PL is only suitable for devices with the following firmware versions:

OMP07T052907A

OMP07ST081007A

B. Upgrade information

The Conceptronic CSM3PL is equipped with an upgradeable firmware chip. This function makes it possible to improve the device and to add new features.

Note: The firmware upgrade procedure is at your own risk. Even though a firmware upgrade can improve the device and add new features, there's also a possibility of an upgrade failure which makes the device unusable. Conceptronic is not responsible for this and this voids the warranty.

Note: This firmware is only for customers who use subtitles that contain characters from the Cyrillic alphabet. This firmware is not for countries that don't use the Cyrillic alphabet.

C. WARNING !!!

There are two different versions of the Conceptronic Media Player on the market. Both versions only differ in hard disk connection type (SATA vs. IDE) and the supplied remote control. Since the devices are so similar it is mandatory to pick out the right product when upgrading the firmware. The easiest way to identify your Media Player is through the remote control.

Below you see an image of both remote controls, continue this firmware upgrade procedure only when you have the **RIGHT** remote control.



D. Upgrade procedure from the internal hard disk of the CSM3PL

1. Copying the firmware files to the CSM3PL

- 1.1 If you have downloaded the firmware upgrade from www.conceptronic.net, you have a ZIP file containing a folder named 'FW' and three documentation files.
- 1.2 Connect the CSM3PL to your computer with the USB cable.
- 1.3 Copy the 'FW' folder including all its content to the hard disk of the CSM3PL.
- 1.4 Remove the CSM3PL from your computer with the 'Safely remove hardware' option.
- 1.5 Disconnect the USB cable of the CSM3PL and turn it off with the switch on the back side.

2. Updating the firmware

- 2.1 Connect the CSM3PL to a TV or monitor.
- 2.2 Turn on the CSM3PL with a remote control.
- 2.3 Select the 'FW' folder by using the navigation buttons on the remote control.
The upgrade process will now start. This will be visible in the upper left corner with the terms 'ERASE' and 'WRITE'.

***Note:** The CSM3PL must not be turned off during the upgrade process. Doing so will result in an unusable product which is not covered by the warranty.*

- 2.4 As soon as the upgrade process is completed, the screen will go black.

***Note:** The device is still turned on. You need to manually turn off the device by pressing the 'POWER' button on the remote control. You can completely turn the device off by turning off the switch on the back side of the device.*

3. Removing the 'FW' folder

- 3.1 Connect the CSM3PL to your computer with the USB cable.
- 3.2 Remove the 'FW' folder from the hard disk. This makes sure the CSM3PL won't start updating again when the 'FW' folder is selected on your TV or monitor.
- 3.3 Remove the CSM3PL from your computer with the 'Safely remove hardware' option.
- 3.4 Disconnect the USB cable from the CSM3PL and turn it off with the switch on the back side.

4. Checking the current firmware version

- 4.1 Make sure the CSM3PL is connected to a TV or monitor.
- 4.2 Select a folder by using the navigation buttons on the remote control.
- 4.3 Press the 'FUNC' button on the remote control, select 'PROPERTIES' and press the 'Enter' button.
- 4.4 Now press the 'Pause' button (II) five (5) times in a row.
- 4.5 Leave the current screen by pressing the 'FUNC' button.
- 4.6 When the 'Fast Forward' button (>>) is pressed, the current firmware version will be shown. This must be: **VER 32-O MP07ST011208A-2L**.
- 4.7 If the version isn't shown long enough, you need to press the 'Fast Forward' button again.
- 4.8 If the displayed version isn't the same as the version described at point 4.6, then you need to repeat the upgrade procedure as described in chapter D.

E. Upgrade procedure from a USB stick or memory card

1. Copying the firmware files to a USB stick or a memory card

- 1.1 If you have downloaded the firmware upgrade from www.conceptronic.net, you have a ZIP file containing a folder named 'FW' and three documentation files.
- 1.2 Connect the USB stick or memory card to your computer.
- 1.3 Copy the 'FW' folder including all its content to the USB stick or memory card.
- 1.4 Remove the USB stick or memory card from your computer with the 'Safely remove hardware' option.
- 1.5 Disconnect the USB stick or memory card from your computer.

2. Updating the firmware

- 2.1 Make sure the CSM3PL is connected to a TV or monitor.
- 2.2 Turn on the CSM3PL with the remote control.
- 2.3 Connect the USB stick to the CSM3PL or slide the memory card in the right card slot of the CSM3PL.
- 2.4 A screen will be displayed in which you can make the choice between 'HARD DISK' and 'USB DEV' / '<memory card>', where '<memory card>' is the used memory card type (for instance 'COMPACT FLASH'). Choose the option of the USB stick or memory card.
- 2.5 Select the 'FW' folder by using the navigation buttons on the remote control.
The upgrade process will now start. This will be visible in the upper left corner with the terms 'ERASE' and 'WRITE'.

Note: *The CSM3PL must not be turned off during the upgrade process. Doing so will result in an unusable product which is not covered by the warranty. The same applies to removing the USB stick or memory card.*

2.6 As soon as the upgrade process is completed, the screen will go black.

Note: The device is still turned on. You need to manually turn off the device by pressing the 'POWER' button on the remote control. You can completely turn the device off by turning off the switch on the back side of the device.

2.7 Remove the USB stick or memory card from the device.

Note: Never do this when the device is turned on and the upgrade process is busy. This will result in an unusable product.

3. Checking the firmware version

3.1 Make sure the CSM3PL is connected to a TV or monitor.

3.2 Select a folder by using the navigation buttons on the remote control.

3.3 Press the 'FUNC' button on the remote control, select 'PROPERTIES' and press the 'Enter' button.

3.4 Now press the 'Pause' button (II) five (5) times in a row.

3.5 Leave the current screen by pressing the 'FUNC' button.

3.6 When the 'Fast Forward' button (>>) is pressed, the current firmware version will be shown.
This must be: **VER 32-O MP07ST011208A-2L.**

3.7 If the version isn't shown long enough, you need to press the 'Fast Forward' button again.

3.8 If the displayed version isn't the same as the version described at point 3.7, then you need to repeat the upgrade procedure as described in chapter E.

F. Release notes

OMP07ST011208A / 1.60:

- Subtitles: Improved “Latin2” character support for countries with Cyrillic alphabet.
- Firmware upgrade procedure changed. From now on a pop-up will show asking you if you want to upgrade or not.

OMP07ST081007A:

- Subtitles: “Latin2” character support for countries like Hungary, Bulgaria, etc.

OMP07T052907A:

- Initial release.