

How to reset your C54AP(T) Access Point when there is no reset hole present.

See an example of the reset hole to see if it is present on your Access Point:



Example without reset hole.





Example with reset hole.

! Warning !

When resetting your Access Point you will loose all settings.

1. Unplug the Access Point from the power and from the network.
2. Place the Access Point upside down.
3. Unscrew both screws at the backside of the Access Point as you can see below.



4. Place the Access Point back on its feet and open the cover a little as you can see below.
5. Connect the power supply.
6. Wait until the Access Point is on.
7. Press the little black reset button for a few seconds
(until the Access Point will switch off, all 3 lights will close)
8. Release the button, after a few seconds the Access Point will turn back on.
9. Unplug the Access Point from the power and close the screws again.



Detail of the reset button:

