

Conceptronic C54PSERVU Printer Compatibility List

Company	Printer Model	Working	Note
Brother	HL-2070	OK	
Brother	HL-5240	OK	
Brother	MFC-210C	OK	
Brother	MFC-215C	OK	
Brother	MFC-2820	OK	
Brother	MFC-3240C	OK	
Brother	MFC-420CN	OK	
Brother	MFC-425CN	OK	
Brother	MFC-4800J	OK	
Brother	MFC-7420	OK	
Brother	MFC-7820N	OK	
Brother	MFC-8840D	OK	
Canon	C350	OK	
Canon	i255	OK	
Canon	i320	OK	
Canon	i355	OK	
Canon	i450	OK	
Canon	i455	OK	
Canon	i475D	OK	
Canon	i550	OK	
Canon	i560	OK	
Canon	i6100	OK	
Canon	i6500	OK	
Canon	i850	OK	
Canon	i865	OK	
Canon	i905D	OK	
Canon	i9100	OK	
Canon	i9950D	OK	
Canon	iC D380	OK	
Canon	iP1000	OK	
Canon	iP1200	OK	
Canon	iP1500	OK	
Canon	iP1880	OK	
Canon	iP2000	OK	
Canon	iP3000	OK	
Canon	iP3300	OK	
Canon	iP3500	OK	
Canon	iP4000	OK	
Canon	iP4200	OK	
Canon	iP4300	OK	
Canon	iP4500	OK	
Canon	iP5000	OK	
Canon	iP6000D	OK	
Canon	iP8500D	OK	
Canon	iP90	OK	

Canon	iR 2010	OK	
Canon	iX4000	OK	
Canon	iX5000	OK	
Canon	PIXMA MP110	OK	
Canon	PIXMA MP130	OK	
Canon	PIXMA MP145	OK	
Canon	PIXMA MP150	OK	
Canon	PIXMA MP160	OK	
Canon	PIXMA MP170	OK	
Canon	PIXMA MP180	OK	
Canon	PIXMA MP450	OK	
Canon	PIXMA MP510	OK	
Canon	PIXMA MP700	OK	
Canon	PIXMA MP730	OK	
Canon	PIXMA MX700	OK	
Canon	Pro 9000	OK	
Canon	Pro9000	OK	
Canon	S200SPx	OK	
Dell	944	OK	
Dell	Mono LaserMFP1125	OK	*
Epson	Aculaser C1900	OK	
Epson	Aculaser C4000	OK	
Epson	Aculaser C4100	OK	
Epson	Aculaser C8600	OK	
Epson	DLQ-3500C	OK	
Epson	EPL-5900L	OK	*
Epson	EPL-6100	OK	
Epson	EPL-6200	OK	
Epson	EPL-N2500	OK	
Epson	EPL-N3000	OK	
Epson	LQ-300+II	OK	
Epson	PictureMate	OK	
Epson	Stylus C110	OK	
Epson	Stylus C4100	OK	
Epson	Stylus C43UX	OK	
Epson	Stylus C45	OK	
Epson	Stylus C63	OK	
Epson	Stylus C67	OK	
Epson	Stylus C83	OK	
Epson	Stylus C88	OK	
Epson	Stylus C90	OK	
Epson	Stylus COLOR 1160	OK	
Epson	Stylus COLOR 740	OK	
Epson	Stylus COLOR 880	OK	
Epson	Stylus COLOR 900	OK	
Epson	Stylus CX1500	OK	
Epson	Stylus CX3100	OK	
Epson	Stylus CX3700	OK	

Epson	Stylus CX3900	OK	
Epson	Stylus CX4100	OK	
Epson	Stylus CX4700	OK	
Epson	Stylus CX5100	OK	
Epson	Stylus CX5300	OK	
Epson	Stylus CX5500	OK	
Epson	Stylus CX5700F	OK	
Epson	Stylus CX5900	OK	
Epson	Stylus CX7300	OK	
Epson	Stylus CX8300	OK	
Epson	Stylus CX9300F	OK	
Epson	Stylus CX9400F	OK	
Epson	Stylus PHOTO 1390	OK	
Epson	Stylus PHOTO 2100	OK	
Epson	Stylus PHOTO 830U	OK	
Epson	Stylus PHOTO 935	OK	
Epson	Stylus PHOTO R210	OK	
Epson	Stylus PHOTO R230	OK	
Epson	Stylus PHOTO R270	OK	
Epson	Stylus PHOTO R310	OK	
Epson	Stylus PHOTO R340	OK	
Epson	Stylus PHOTO R350	OK	
Epson	Stylus PHOTO RX430	OK	
Epson	Stylus PHOTO RX510	OK	
Epson	Stylus PHOTO RX520	OK	
Epson	Stylus PHOTO RX530	OK	
Epson	Stylus PHOTO RX590	OK	
Epson	Stylus PHOTO RX630	OK	
Epson	Stylus PHOTO RX650	OK	
Epson	Stylus PHOTO750	OK	
HP	Business 1000	OK	
HP	Business 1100d	OK	
HP	Business 1200d	OK	
HP	CLJ 1500L	OK	
HP	CLJ 1600	OK	
HP	CLJ 2550L	OK	
HP	CLJ 2600n	OK	
HP	CLJ 3500	OK	
HP	CLJ 3500N	OK	
HP	CLJ 3600	OK	
HP	CLJ 3600dn	OK	
HP	CLJ 3600n	OK	
HP	CLJ 3700	OK	
HP	CLJ 4600	OK	
HP	CLJ CP3505	OK	
HP	CLJ3000dn	OK	
HP	CM1015MFP	OK	
HP	CM1017MFP	OK	

HP	Deskjet 1120C	OK	
HP	Deskjet 1180C	OK	
HP	Deskjet 3325	OK	
HP	Deskjet 3535	OK	
HP	Deskjet 3550	OK	
HP	Deskjet 3650	OK	
HP	Deskjet 3820	OK	
HP	Deskjet 3920	OK	
HP	Deskjet 450	OK	
HP	Deskjet 5160	OK	
HP	Deskjet 5440	OK	
HP	Deskjet 5550	OK	
HP	DeskJet 5652	OK	
HP	DeskJet 5740	OK	
HP	Deskjet 6122	OK	
HP	DeskJet 6540	OK	
HP	DeskJet 6840	OK	
HP	Deskjet 810C	OK	
HP	DeskJet 845C	OK	
HP	Deskjet 880C	OK	
HP	Deskjet 882C	OK	
HP	Deskjet 895cxi	OK	
HP	Deskjet 920C	OK	
HP	Deskjet 9300	OK	
HP	Deskjet 960	OK	
HP	Deskjet 9650	OK	
HP	Deskjet 970cxi	OK	
HP	Deskjet 980	OK	
HP	Deskjet 990	OK	
HP	Deskjet 995C	OK	
HP	Deskjet D2360	OK	
HP	Deskjet D4260	OK	
HP	Deskjet F2180	OK	
HP	Deskjet F380	OK	
HP	Deskjet F4185	OK	
HP	DeskJet845C	OK	
HP	LaserJet 1010	OK	
HP	LaserJet 1012	OK	
HP	LaserJet 1015	OK	
HP	LaserJet 1018	OK	
HP	LaserJet 1022	OK	*
HP	LaserJet 1200	OK	
HP	LaserJet 1220	OK	
HP	LaserJet 1300	OK	
HP	LaserJet 1320	OK	
HP	LaserJet 2300	OK	
HP	LaserJet 2300L	OK	
HP	LaserJet 2420	OK	

HP	LaserJet 2420dn	OK	
HP	LaserJet 2605	OK	
HP	LaserJet 2700	OK	
HP	LaserJet 3015	OK	
HP	LaserJet 3020	OK	
HP	LaserJet 3030	OK	
HP	LaserJet 3050	OK	
HP	LaserJet 3050z	OK	
HP	LaserJet 3052	OK	
HP	LaserJet 3055	OK	
HP	LaserJet 3200	OK	
HP	LaserJet 3300	OK	
HP	LaserJet 3330MFP	OK	
HP	LaserJet 3380	OK	
HP	LaserJet 3390	OK	
HP	LaserJet 3392	OK	
HP	LaserJet 4350	OK	
HP	LaserJet 4650	OK	
HP	LaserJet 5200L	OK	
HP	LaserJet M1005MFP	OK	
HP	LaserJet P2015	OK	
HP	OfficeJet 4110	OK	
HP	OfficeJet 4255	OK	
HP	OfficeJet 4355	OK	
HP	OfficeJet 5110	OK	
HP	OfficeJet 5510	OK	
HP	OfficeJet 5610	OK	
HP	OfficeJet 6110	OK	
HP	OfficeJet 6210	OK	
HP	OfficeJet 6310	OK	
HP	OfficeJet 7130	OK	
HP	OfficeJet 7210	OK	
HP	OfficeJet 7410	OK	
HP	OfficeJet 9100	OK	
HP	OfficeJet 9110	OK	
HP	OfficeJet 9120	OK	
HP	OfficeJet 9130	OK	
HP	OfficeJet J5780	OK	
HP	OfficeJet Pro K5300	OK	
HP	OfficeJet Pro K5400	OK	
HP	OfficeJet Pro K5400dn	OK	
HP	OfficeJet Pro K550	OK	
HP	OfficeJet Pro K850	OK	
HP	OfficeJet Pro K850dtn	OK	
HP	OfficeJet Pro L7380	OK	
HP	OfficeJet Pro L7580	Ok	
HP	OfficeJet V40	OK	
HP	Photosmart 145	OK	

HP	Photosmart 245	OK	
HP	Photosmart 2575	OK	
HP	Photosmart 2610	OK	
HP	Photosmart 2710	OK	
HP	Photosmart 3110	OK	
HP	Photosmart 325	OK	
HP	Photosmart 3310	OK	
HP	Photosmart 375	OK	
HP	Photosmart 475	OK	
HP	Photosmart 7260	OK	
HP	Photosmart 7450	OK	
HP	Photosmart 7550	OK	
HP	Photosmart 7660	OK	
HP	Photosmart 7760	OK	
HP	Photosmart 7830	OK	
HP	Photosmart 7960	OK	
HP	Photosmart 8030	OK	
HP	Photosmart 8230	OK	
HP	Photosmart 8250	OK	
HP	Photosmart 8450	OK	
HP	Photosmart 8750	OK	
HP	Photosmart A526	OK	
HP	Photosmart C3180	OK	
HP	Photosmart C4180	OK	
HP	Photosmart C4280	OK	
HP	Photosmart C4385	OK	
HP	Photosmart C5180	OK	
HP	Photosmart C6180	OK	
HP	Photosmart C6280	OK	
HP	Photosmart C7180	Ok	
HP	Photosmart C7280	OK	
HP	Photosmart D5160	OK	
HP	Photosmart D7160	OK	
HP	Photosmart D7360	OK	
HP	PSC 1110	OK	
HP	PSC 1210	OK	
HP	PSC 1315	OK	
HP	PSC 1350	OK	
HP	PSC 1410	OK	
HP	PSC 1510	OK	
HP	PSC 1610	OK	
HP	PSC 2110	OK	
HP	PSC 2210	OK	
HP	PSC 2310	OK	
HP	PSC 2355	OK	
HP	PSC 2410	OK	
HP	PSC 2510	OK	
HP	PSC 4110	OK	

HP	PSC 750	OK	
Konica Minolta	Magicolor 2480MF	OK	*
Konica Minolta	Magicolor 5550	OK	
Konica Minolta	Magicolor 5570	OK	
Lexmark	C510	OK	
Lexmark	E120	OK	
Lexmark	E230	OK	
Lexmark	P4350	OK	
Lexmark	X6170	OK	
Lexmark	Z1420	OK	
Lexmark	Z603	OK	**
Lexmark	Z615	OK	**
Lexmark	Z705	OK	**
Lexmark	Z810	OK	**
Lexmark	Z816	OK	**
Lexmark	Z818	OK	**
SAMSUNG	ML-1520LP	OK	
SAMSUNG	ML-1740	OK	
SAMSUNG	ML-2010	OK	
SAMSUNG	SCX-4100	OK	
SAMSUNG	SCX-4200	OK	
SAMSUNG	SCX-4521F	OK	
SAMSUNG	SCX-4720F	OK	
SAMSUNG	SF-565P	OK	

Notes:

- * This model needs to close bi-directional function.
- ** For some Lexmark printers, close bi-directional and choose "WinPrint" processor and RAW printing protocol.