



**CMULTICRSI
(C05-120)**

Card Compatibility List

CF (Compact Flash)	
	CF Type I
	CF Type II
	CF Ultra
	CF Ultra II
	CF Extreme (III)
	CF Elite Pro Card
	CF Ultimate
	CF Ultra-X
MD (Micro Drive Card)	
	IBM Micro Drive Card
	SONY Micro Drive Card
XD (Extreme Digital-Picture Card)	
	XD
	XD Type M
	XD Type H
SD (Secure Digital)	
	SD
	SD Ultra
	SD Ultra II (Plus)
	SD Extreme
	SD Extreme III
	Mini SD
	Mini SDHC
	SDHC (CLASS2、4、6)
	Micro SD (Trans-Flash)

MMC (Multi Media Card)	
	MMC
	MMC 4.0
	MMC Plus
	RS-MMC (Reduced sized MMC)
	RS-MMC 4.0
	RS-MMC DV
	RS-MMC mobile
	MMC micro
MS (Memory Stick)	
	MS
	MS Select
	MS Magic Gate
	MS Select Magic Gate
	MS Pro
	MS Pro High-Speed
	MS Pro Magic Gate
	MS Duo
	MS Duo Magic Gate
	MS Pro Duo
	MS Pro Duo Magic Gate
	MS Pro Duo High-Speed
	MS Micro (M2)
	MS Pro-HG
	MS Pro-HG Duo
	MS Rom
	MS Pro Ultra II
	MS Pro Extreme
	MS Pro Extreme II
	MS Pro Extreme III
	MS Pro Duo Ultra II
	MS Pro Duo Extreme II Magic Gate