



JP1 IEEE1394

1.TPA+(BLUE)	2. TPA-(ORANGE)
3.GND (BLACK)	4. GND (BLACK)
5.TPB+(GREEN)	6. TPB-(RED)
7.12V (WHITE)	8. 12V (WHITE)
9.NC	10.GND (BLACK)

JP3 EAR_PHONE

1. NC	2. MIC1 (BLACK)
3. MIC_GND (S-BLACK)	4. MIC1 (BLACK)
5. MIC2 (RED)	6. MIC2 (RED)
7. L_IN_GND (S-BLACK)	8. LINE_IN1 (WHIET)
9. LINE_IN2 (YELLOW)	10.LINE_IN1 (WHIET)
11.LINE_OUT1(BROWN)	12.LINE_IN2 (YELLOW)
13.L_OUT_GND(S-BLACK)	14.LINE_OUT1(BROWN)
15.LINE_OUT2(GREEN)	16.LINE_OUT2(GREEN)

JP2 USB 2.0

1.5V (RED)	2. 5V (RED)
3.D- (WHITE)	4. D- (WHITE)
5.D+ (GREEN)	6. D+ (GREEN)
7.GND(BLACK)	8. GND(BLACK)
9.NC	10.NC

JP4 RCA & MINI_DIN

1. RCA-1 (WHITE)	2. RCA-2 (BLACK)
3. NC	4. NC
5. M-DIN3(RED)	6. M-DIN5(YELLOW)
7. M-DIN6(BROWN)	8. M-DIN8(ORANGE)
9. NC	10.GND (BLACK)