









Powercable & tip overview

| Powercable picture | Powercable description |
|---|------------------------|
|  | USB-to-DC power cable |

| Tip | Tip Picture | Compatible devices |
|-----|---|--|
| A |  | All mobile devices with Micro-USB charging port, like Nokia N85, Nokia 6500, Motorola V70, Motorola V8. |
| B |  | MP3 / MP4 / PDA / PMP, <u>Digital Camera:</u> Kyocera/Casio/Canon/Casio/Kodak/ Minolta/Olympus/Pentax/Samsung |
| C |  | SONY PSP, MP3 / MP4 / PDA / PMP, <u>Digital Camera:</u> Canon/Casio/Fujitsu/Kodak/ Nikon/Olympus/Panasonic |
| D |  | <u>Nokia:</u> 1600/2300/2310/2600/2610/2626/2652/3100/3120/ 3220/3230/3300/3310/5140/6020/6021/6030/6060/ 6100/6170/6230/ 6230i/6600/ 6610i/6670/6680/ 6820/7260/7270/7280/7610/7710/8800/9300/ E70 |
| E |  | <u>Nokia:</u> 1325/1650/2112/2255/2310/2505/2610/2630/2660/ 2760/3125/3250/3500/3610/5070/5120/5200/5300/ 5500/5310/5610/5700/6060/6070/6085/6101/6103/ 6110/6111/6120/6125/6131/6151/6233/6235/6267/ 6270/6280/6288/6290/6300/6500/7360/7370/7373/ 7380/7390/7500/7900/E50/E61/E65/N70/N71/N73/ N76/N77/N80/N81/N82/N90/N91/N93/N93i/N95 |
| F |  | All mobile devices with Mini-USB charging port, like HTC Diamond2, HTC Snap, Blackberry, Motorola ROKR series, PDA, GPS adapters. |
| G |  | Apple iPhone, Apple iPod |