

How to update the firmware of the CHD3LAN

We recommend to use a direct LAN / network cable between your computer and the CHD3LAN for updating the firmware.

Goto <http://169.254.0.1> (default IP-address of the CHD3LAN) or //storage (default hostname of the CHD3LAN)

Check if you use Firmware version NAS-BASIC45, LOADER 69 (visible within the "Status" page).

When you do not have this firmware, you need to update the firmware first to version NAS-BASIC45, LOADER 69.

You can download this version with the following link:

http://download.conceptronic.net/Connectivity/CHD3LAN/CHD3LAN_FW_B45_L69.exe

Read the included CHD3LAN_How_To_Update.pdf before updating.

When you have firmware version NAS-BASIC45, LOADER 69 then perform the following steps:

Click "Maintenance"

Click "Browse"

Go to the directory where the firmware is extracted to (default C:\Conceptronic\CHD3LAN)

Select "conceptronic47-b4.bin"

Click "Upload"

Click "OK"

Wait until you get the message "Upgrade firmware successfully! Please reboot system!"

Wait for about 1 minute before you reboot the CHD3LAN.

Reboot the CHD3LAN.

The CHD3LAN needs to be set to it's factory defaults to ensure the proper function of the CHD3LAN.

Turn off the CHD3LAN

Hold down the reset button (on the backside of the CHD3LAN)

Turn on the CHD3LAN (still holding down the reset button)

Wait 20 seconds release the reset button.

The CHD3LAN is set to it's factory defaults and can be configured to your settings.

Please Note!

Firmware updates are at own risk on usage