

Firmware upgrade instructions for the Conceptronic CPSERVU print server



These instructions will explain how to upgrade the firmware of the Conceptronic CPSERVU print server.

1. Start the PS-Utility and let it discover the device.
2. Under '**Device Name**' select the device of which you want to upgrade the firmware. Normally only one device is shown, unless you have multiple Conceptronic print servers.
3. Click on the '**Show Web Setup**' button.
4. The web setup will be shown in your web browser, click on '**Firmware Upgrade**' on the left.
5. Click on '**Browse**' and locate the '**CPSERVU.BIN**' firmware file. Once selected, click on '**Open**'.
6. The path to the firmware is shown, click on the '**Upgrade**' button.
7. The firmware upgrade will now be applied. Once completed, the following message will be shown: "**Firmware upgrade completed**".
8. To ensure yourself the firmware upgrade succeeded, we advice you to check the firmware version. First click on '**Home**' and then on '**Firmware Upgrade**'. The firmware version that needs to be shown is '**4.06**'. If this is not the case, please follow the upgrade instructions again.