

Conceptronic CM3PVR - DVD Playback & AVI Subtitle Instructions for firmware version 038 and later versions



A. DVD Playback Instructions

From firmware version 038, the CM3PVR supports DVD Playback functionality.

Note: The CM3PVR only supports the playback of unprotected DVD copies. CSS protection is not supported by the CM3PVR.

To play DVD files from the CM3PVR, follow the instructions below:

1. Create a folder on the CM3PVR hard disk in the '**VIDEO**' folder with the name of your DVD movie (for example: '**Movie1**').
2. Copy the '**AUDIO_TS**' and '**VIDEO_TS**' including content from your DVD to the created folder (for example: '**Movie1**') on the CM3PVR.

After copying, the structure should be:

- VIDEO

|-> **Movie1**

 |-> **AUDIO_TS** (optional)

 |-> **VIDEO_TS** (with all the DVD files inside)

3. Connect the CM3PVR to your TV and power on the CM3PVR.
4. Select '**Movies**' in the main menu of the CM3PVR.
5. Select '**C:/**' in the Movie browser.
6. Select '**VIDEO**' in the Movie browser.

In the folder '**VIDEO**', your movie should be listed (for example: as '**Movie1**') with a DVD icon in front of it.

7. Select the movie folder and press the '**PLAY/PAUSE**' button on your remote control.

The DVD playback will now start.

Note: If you press '**ENTER**' instead of '**PLAY/PAUSE**', the CM3PVR will not play the DVD movie, but will open the (movie) folder.

Remote Control functions during DVD Playback

Button	Function(s)
Navigation buttons	Navigate through the DVD Menu.
ENTER	Confirm DVD Menu selection(s).
SUBTITLE	Change or turn off the subtitle of the DVD.
AUDIO	Change the audio track of the DVD (when the DVD contains multiple audio tracks).
ANGLE	Change the playback angle of the DVD (when the DVD contains multiple angles).
FF	Fast Forward
FR	Fast Rewind
NEXT	Next Chapter
PREVIOUS	Previous Chapter
MENU	Return to the DVD Menu.
TITLE	Return to the DVD Menu.
STOP	Stop the playback of the DVD and return to the Movie browser.

B. AVI Subtitle Instructions

From firmware 038, the CM3PVR supports the following subtitle files:

- SRT
- SSA
- SUB
- SMI

To play AVI files with subtitles, you need to assign the same name to the subtitle file as the AVI file.

For example:

Movie name: **My_Movie_With_Sub.AVI**

Subtitle name: **My_Movie_With_Sub.SRT**

Select the AVI file you want to play and press the 'ENTER' or 'PLAY/PAUSE' button on the remote control. The AVI file will start playing with the corresponding subtitle file loaded.

To disable/enable subtitles during playback, press the 'SUBTITLE' button on the remote control.

The subtitle files are also listed in the browser menu when 'Movies' is selected from the main menu, so you can also copy subtitles to other locations.