

Quick Connection Guide

Network Video Surveillance Recorder

CONNECTING YOUR SYSTEM *Not included/sold separately

1 **Cameras***



Connect the Cameras

To connect camera to the NVR, get an Ethernet cable and connect the camera RJ45 socket by one end; connect one of the 4 ports on NVR by the other end of this cable.

Repeat this step if there are more cameras to be connected.

2 **Monitor/TV***



Connect the NVR to a Monitor/TV

The NVR supports HDMI and VGA for the video output. Connect NVR either HDMI or VGA port to the Monitor/TV.

If the TV/Monitor supports HDMI input, the video output through HDMI is the most recommended.

3 **Router***



Connect the NVR to a network

Connect NVR LAN port to a router or switch that is in a network. The NVR can then be remotely accessed through Intranet or Internet, e.g. Mobile Apps or remote PC client.



4 **Mouse**



Connect the Mouse

Connect a USB mouse (or the one included in the package) to either of the two front USB ports. The mouse will be utilized for most of NVR local operations.

Note: The rear USB port is suggested to be reserved for external HDD.

5 **Power**



Connect the power adapter

Up to now, the connections in previous steps are all completed. The NVR can now be powered up by plugging in the power adapter.

PACKAGE CONTENTS



Network Video Recorder



Flex IR Extender



Power Adapter



Screws Pack



Quick Connection Guide



Product CD



*Remote Control



*USB mouse

*The actual items maybe different from the picture shown