

This installation requires:

- A Conceptronic Bluetooth headset (CBTHS)
- A computer with soundcard and drivers for that card installed!
- A Conceptronic Bluetooth device with Conceptronic BT software at least version 1.3.2.7 [Download here from Conceptronic](#) or:
- A Bluetooth device that supports the headset and audiogateway profiles.

Follow the next steps:

- Open the bluetooth environment (double click the BT icon in your taskbar)
- Go to **View My Bluetooth services** under Bluetooth Tasks
- Check if the **My Audio Gateway** and **My Headset** are enabled, if not:
- Right click **My Audio Gateway** → click **Enable**
- Right click **My Headset** → click **Enable**

Switch the headset to pairing mode (hold the switch/talk button for 3 seconds)

- Open the bluetooth environment (double click the BT icon in your taskbar)
- Go to View devices in range, Windows will find the Earbridge.
- Double click the Earbridge, Windows will search the services that the Earbridge has to offer
- You will now be asked to enter the pincode on the computer
- Enter **0000** and click Ok

The Headset is now paired with your computer.

- One push on the switch/talk button will enable the connection, you will see **Bluetooth connection succesfull** on the computer
- Another push will break the connection and the computer soundcard will play again.